






# MS-500 OPTIMUM AMPLIFIER PINOUT



## REMINDER

There are only two I/O's available on the MS-500 Optimum Amplifier. If you use a two button wall plate you are using both I/O's that are available.